

## Get Started with Ekso EVO

### Step 1: Install the Springs



1. Turn the actuator "ON"



2. Lift arm up



3. Screw spring into actuator



4. Lower arm and turn actuator "OFF"

### Step 2: Put on Waist Belt



1. Drape Ekso EVO over your shoulders



2. Buckle and tighten waist belt straps



3. Center hip pads on top of your hip bones



4. Tuck in excess webbing

### Step 3: Put On Arm Cuffs



1. Position the arm cuff in the middle of your bicep



2. Tighten the arm cuff straps

### Step 4: Turn on Ekso EVO



1. Keep your arm down at your side



2. Turn the actuator "ON"



## Basic Fit Adjustments with Ekso EVO

### Step 1: Adjust the Torso Length



1. The top of the actuators should line up with the top of your shoulders



2. Press the button pin in, and slide the torso tubes to adjust the length



3. Use a different torso tube length if needed (sm, med, lg)

### Step 2: Adjust the Waist Belt



1. Adjust ratchet straps



2. The hip pads should be centered over your hip bones when is tightened

### Step 3: Adjust the Arm Cuffs



1. Reposition to center of bicep and re-tighten



2. Use a different arm cuff size if needed (sm, med, lg)



Scan to view  
Ekso EVO Operators Manual



101 Glacier Point, Suite A  
San Rafael, CA 94901  
(510) 984-1761  
[www.eksobionics.com](http://www.eksobionics.com)  
©Ekso Bionics, Inc. All Rights Reserved